



Kensai MKII

User Guide
Written October 2015

Specifications:

Size:	16cm x 29cm x 20cm WHD
Weight, Each / Pair In Case:	4Kg / 10Kg
Frequency Range:	48Hz-26KHz -6dB
Recommended Amplifier Power:	>40watts
Sensitivity:	86dB
Impedance:	6 Ohm Minimum
Crossover:	1.9KHz, Phase Aligned 4th order
Bass Alignment:	Extended Bass Shelf
Connection:	2x Binding Posts. Accept bare wire, 4mm banana, 8mm spade

Care:

Do not over-tighten the binding posts.

Do not place the Kensai on stands with spiked top-plates. The bottom of the Kensai will be marked.

The Kensai can play loud for a speaker of their size, but if they begin to distort, or 'chuffing' sounds are heard from the port, then reduce the volume immediately. As a guide, if they sound good, they are probably okay.

To clean the Kensai leatherette, use a slightly damp microfiber cloth. To restore shine of the side panels, buff with a dry microfiber cloth. To remove dirt from the side panels a damp cloth can be used but the sides should be dried and buffed directly afterwards to avoid moisture ingress.

Natural wood can change colour when exposed to sunlight for an extended time.

Avoid placement next to a direct heat source such as active radiator.

Handle the Kensai with care at all times.

Warranty:

The Kensai warranty is valid for 2 years from the date of purchase. It covers the cost of repair or replacement due to defects in materials and/or manufacturing faults.

The warranty does not cover damage or defects caused by:

- a) unauthorised modification of the unit; or
- b) accidental damage.

All claims must be accompanied by proof of purchase.